


This overview shows the maximum possible vehicle equipment.

## Opening the vehicle

These notes apply exclusively to trained emergency service personnel. Knowledge of the function and operating principle of the safety systems and vehicle characteristics is also needed.



1. The areas mark the zones at which the roof can be cut off:

Cut at the top of the windscreen frame as far towards the outside as possible and parallel to the A-pillar. Use a spreading tool to remove the roof outer skin from the C-pillar and cut through the soft top linkage using a parting-off grinder.

Modern heavy duty cutting equipment is mandatory for cutting the body. Older hydraulic cutting tools could be overloaded.

The heavy duty cutting equipment must be properly used by trained and qualified personnel.

- 2. Door locks
- 3. Door hinges

## Important information

The information for the rescue personnel needs to be adhered to, see rescue manual.