


5-door | build from 2024














Note: The illustration shows the maximum possible range of equipment.

Airbag		Stored gas inflator	Seat belt pretensioner	₽	SRS control unit	-	Gas strut / preloaded spring
High-strength zones	00000	Battery pack, low-voltage	Fuel tank				



5-door | build from 2024





1. Identification/recognition





Label on the front grill and the rear tailgate.


2. Immobilisation / stabilisation / lifting

Immobilize the vehicle

Vehicles without electronic parking brake



Apply the parking brake.



Jacking points.

Turn off the ignition





NOTE: Instead of a radio key, it is also possible to use a key card or smartphone app.

Press the "START-STOP" button on the steering rack.



5-door I build from 2024






3. Disable direct hazards / safety regulations

Disconnect the 12-volt battery





- 1. Loosen the nut.
- 2. Disconnect the electrical connector and position aside the battery negative (-) terminal.

4. Access to the occupants



Glass types:

- 1. Laminated safety glass
- 2. Toughened safety glass



Glas types: Toughened safety glass



1. Unlock the steering column

1.

- 2. Adjust the steering wheel
- 3. Lock the steering column



5. Stored energy / liquids / gases / solids









42 I









12 Volt

E377212



5-door | build from 2024





6. In case of fire










E377214

8. Towing / transportation / storage



Do not tow a vehicle that has been involved in an accident on its drive axles.

10. Explanation of pictograms used

Vehicle on Vehicle on Use water to Hazardous Environment fuel of liquid fuel of liquid General extinguish to the human al hazard Flammable group 2 group 1 warning sign the fire health Remove **Bonnet** smart key Explosive

Use thermal

d ir ∭

Infrared

camera