


4 door, 5 seater, Sedan 2022 -











Airbag



Stored gas inflator



Seat belt pretensioner



SRS control unit



Pedestrian protection active system



Automatic rollover protection system



Gas strut /Preloaded spring



High strength zone



Zone requiring special attention



Battery low voltage



Ultra capacitor, low voltage



Fuel tank



Gas tank



Safety valve



High voltage battery pack



High voltage power cable /component



High voltage disconnect



Fuse box disabling high voltage system



Ultra capacitor, high voltage



Gas line

ID NO.	Version NO.	Page NO.
	01	1/4



4 door, 5 seater, Sedan 2022 -



1. Identification / recognition



Silent movement or instant restart capability exists until vehicle is fully shut down.







Model name Brand name

2. Immobilisation / Stabilisation / Lifting

A. IMMOBILIZE THE VEHICLE:

- 1. Shift the vehicle to P gear;
- 2. Turn on the hazard warning lamp on the central console.



B. LIFTING POINTS:





Appropriate lifting points



Appropriate points vehicle on side



High voltage battery

3. Disable Direct Hazards / Safety Regulations



Be aware that not every high voltage component is labelled.

Always wear the appropriate PPE (Rubber insulated gloves / insulated rubber shoes / tools with insulating protective cover / goggles). Do not attempt to open the high voltage battery.

MAIN DISABLING METHOD









ACCESS TO 12V BATTERY











ID NO.	Version NO.	Page NO.
	01	2/4



4 door, 5 seater, Sedan 2022 -



4. Access to the Occupants



Driver seat adjustment (electric)



Exterior door handle



Passenger seat adjustment (electric)



Emergency interior door handle



Steering column adjustment



Door latch

Glass types:

Laminated glass



Tempered glass

5. Stored Energy / Liquids / Gases / Solids



6. In Case of Fire



USE LARGE AMOUNTS OF WATER















BATTERY RE-IGNITION!



DO NOT SUBMERGE VEHICLE TO EXTINGUISH BATTERY

ID NO.	Version NO.	Page NO.
	01	3/4



4 door, 5 seater, Sedan 2022 -




7. In Case of Submersion

Tilt the vehicle to one side to allow water to drain out of the vehicle and the high voltage battery.

Wear appropriate PPE. Remove the vehicle from the water and continue with normal high voltage disconnection (see chapter 3). Vehicles submerged in salt water should be handled with a greater potential risk of a high voltage battery fire.

8. Towing / Transportation / Storage

STORE AT SAFE DISTANCE FROM OTHER VEHICLES!





BATTERY RE-IGNITION!



Hook storage



Hook location

9. Important Additional Information

Manufacturer information NIO

For further details, please refer to "Emergency Response Guide".

10. Explanation of Pictograms Used

4	Warning high voltage	(N)	Flammable
	Caution	\$	Hazardous to the human health
*	Air-conditioning component		Acute toxicity
4	Electric vehicle		Corrosives
	Bonnet	\Diamond	Gases under pressure
	Boot		Explosive
<u></u>	Use thermal Infrared camera		Use water to extinguish the fire

ID NO.	Version NO.	Page NO.
	01	4/4